

D/M 100 Setup table

Default




Om-gryphon Default



Enter config



Save config



Set Radio Address



0.0.0.0⁴

Bind



Cradle UP

Join



Wedge IBM AT or PS2



RS-232C



*9600



19200



*None



Even



Odd



*8 Bits



7 Bits



2 Stop Bit



No Header



One Header



No Terminator



*One Terminator



*Code 39 Standard



Code 39 Full Ascii



*No Check Digit



Check Digit & Trans



Check Digit Not Trans



HEX / NUMERIC TABLE

CHARACTER TO HEX CONVERSION TABLE					
char	hex	char	hex	char	hex
NUL	00	^	2A	U	55
SOH	01	+	2B	V	56
STX	02	.	2C	W	57
ETX	03	-	2D	X	58
EOT	04	:	2E	Y	59
ENQ	05	!	2F	Z	5A
ACK	06	0	30	[5B
BEL	07	1	31	\	5C
BS	08	2	32]	5D
HT	09	3	33	^	5E
LF	0A	4	34	?	5F
VT	0B	5	35	a	60
FF	0C	6	36	b	61
CR	0D	7	37	c	62
SO	0E	8	38	d	63
SI	0F	9	39	e	64
DLE	10	:	3A	f	65
DC1	11	:	3B	g	66
DC2	12	<	3C	h	67
DC3	13	=	3D	i	68
DC4	14	>	3E	j	69
NAK	15	?	3F	k	6A
SYN	16	@	40	l	6B
ETB	17	A	41	m	6C
CAN	18	B	42	n	6D
EM	19	C	43	o	6E
SUB	1A	D	44	p	6F
ESC	1B	E	45	q	70
FS	1C	F	46	r	71
GS	1D	G	47	s	72
RS	1E	H	48	t	73
US	1F	I	49	u	74
SPACE	20	J	4A	v	75
!	21	K	4B	w	76
"	22	L	4C	x	77
#	23	M	4D	y	78
\$	24	N	4E	z	79
%	25	O	4F	[7A
&	26	P	50	\	7B
'	27	Q	51]	7C
(28	R	52	^	7D
)	29	S	53	~	7E
		T	54	DEL	7F



Code 93 Enable



Code 128 Enable



Disable All Code



*No Decoding Safety



Two Reads Decode



Four Reads Decode



*Hardware Trigger



Automatic



Always On

